



Working Process: Infrared Drying

Why choose infrared drying?

- ✓ Higher shop output with excellent through-drying
- ✓ Time savings
- ✓ Lower energy consumption
- ✓ Greater economy

How to use Infrared drying?

- ✓ The distance between the panel and infrared depends on the equipment used. Refer to the manufacturer's instructions.
- ✓ Observe safety rules and regulations.

This guide for drying time is based on: (Infrared distance 2 ft. / 60 cm)

Standox Products	Medium wave		Short wave		
	Flash off time without IR	100% Power	Flash off time without IR	50% Power (flash off power)	100% Power
Standox Polyester Stoppers and 2K Fillers	5 min 5 min	5 – 7 min 15 min 10 – 12 min	5 min 5 min	2 – 3 min 10 min 2 min PLUS	10 – 14 min
Standoblue Basecoat: Dark colors Light colors		3 min 4 – 6 min		2 min 3 – 4 min	
Standocryl [®] 2K Paints: Dark colors	5 min	12 min	5 min	12 min	*1
Standocryl 2K Clears: Dark colors Light colors	5 min 5 min	13 – 16 min 15 – 18 min	5 min 5 min	13 – 16 min 3 min PLUS	*1 10 – 12 min

*1 = if too hot solvent pop can occur

Important Technical Remarks:

- Drying times may vary from unit due to different models and different heating elements.
- If Infrared drying is used, each film should be individually dried to prevent peeling and solvent popping.
- Actual film thickness will affect dry times with thicker films requiring additional times.

Important Legislative Remarks:

- Any analytical results set forth herein do not constitute a warranty of specific product features or of the product's suitability for a specific purpose. All products are sold pursuant to our general conditions of sale. We hereby disclaim all warranties and representations, express or implied, with respect to this product, including any warranty of merchantability or fitness for a particular purpose. This product is protected by patent law, trademark law, copyright law, international treaties and/or other applicable law. All rights reserved. Unauthorized sale, manufacturing or use may result in civil and criminal penalties.