





Metalux™ 1056 Blending Additive




COMPONENTS
Metalux 1056 Blending Additive
Reducers (1156, 1157, 1158)




APPLICATION
1 coat
4 – 8 minute flash off before
applying colors over wet bed




MIX RATIO
2 : 1



DRY TIME
To Clearcoat – 15 – 20 minutes



VISCOSITY
Ford #4
16 seconds



VOC
779 grams / liter
6.5 lbs / gallon



GENERAL

DESCRIPTION

1056 Blending Additive is a specialized, colorless basecoat designed for tri-coats, wet beds, intercoat clear, design work and light or hard to control metallics. Color blender is not intended for use as a durable topcoat clear, it must be over coated with clearcoat. Specially formulated to be intermixed with Metalux topcoats.

The products referenced herein may not be sold in your market. Please consult your distributor for product availability.



MIXING

COMPONENTS

Wet bed-intercoat clear: Mix 2 parts Metalux 1056 Blending Additive to 1 part Metalux Universal Reducer (1156, 1157, or 1158)

Translucent blending procedure: Add equal amounts of reduced Metalux Blending Additive 1056 to the remaining reduced Metalux basecoat and mix well. This creates a translucent basecoat to be used in the blending process only, when spraying difficult colors.

Option for longer recoating: Add 5% MS hardener to premixed basecoat.

Component

Metalux 1056 Blending Additive
Metalux Universal Reducers
(1156 Fast, 1157 Medium, 1158 Slow)

Volume

2
1

Package Size

- 1 gallon (3.75 liters)

INITIAL APPLICATION VISCOSITY

Ford #4 Viscosity 16 seconds



APPLICATION

APPLICATION EQUIPMENT

HVLP Gravity	1.3 - 1.4 mm	1.0 - 1.5 (Bar)	6 - 8 PSI	*At the cap
High Efficiency	1.3 - 1.4 mm	1.0 - 1.5 (Bar)	17 - 19 PSI	At gauge

NOTE: Refer to spray gun manufacturer for further information regarding HVLP Inlet Pressures

APPLICATION

Wet Bed: Apply a single coat with 4 - 8 minute flash off before applying basecoat colors over wet bed.

Translucent blending: Apply an additional coat of this translucent basecoat color, blending out past the repair area.

RECOAT

Blending Additive must be clearcoated for durability. Allow Blending Additive and basecoat to thoroughly flash before applying clearcoat. Apply clearcoat within 12 hours or extend up to 24 hours when hardener is added to the basecoat. Cooler temperatures may require longer flash times.



DRY TIMES

AIR DRY

75°F (23°C)

Hand Slick	5 Minutes
Dust Free	5 Minutes
Tape Free	20 Minutes
To Clearcoat	15 – 20 Minutes
To Handle	Overnight (after clear)



PHYSICAL PROPERTIES

Recommended Film Thickness	± 10 microns / 0.39 mils per coat
VOC as Applied	6.5 lbs/gallon (RFU)
Mixed Volume Solids	11-13% (Average)
Theoretical Coverage	Approx. 193 SqFt @ 1 Mil DFT/mixed gallon
Recommended Coats	2-3 (x1)
DFT per Coat	Approximately 0.5 mil
Ford #4 Viscosity	16 Seconds

STORAGE CONDITIONS

Store in a dry, well ventilated area. Storage temperatures should be between -30°F (-34°C) and 120°F (48°C).



VOC REGULATED AREAS

Max VOC (LE): 791.8 g/L (6.6 lbs./gal)
Max VOC (AP): 791.3 g/L (6.6 lbs./gal)
Avg. Gal. Wt: 7.71 lbs./gal
Avg. Wt.% Volatiles: 85.682%
Avg. Wt.% Exempt Solvent: 0%
Avg. Wt.% Water: 0.076%
Avg. Vol.% Exempt solvent: 0.0%
Avg. Vol.% Water: 0.071%
Flash Point: See SDS
Theoretical Coverage: 184.66 Sq Ft/Gal at 1 Mil

These directions refer to the use of products which may be restricted or require special mixing instructions in VOC regulated areas. Follow mixing usage and recommendations in the VOC Compliant Products Chart for your area.

SAFETY AND HANDLING

For industrial use only by professional, trained painters. Not for sale to or use by the general public. Before using, read and follow all label and SDS precautions. If mixed with other components, mixture will have hazards of all components.

Ready to use paint materials containing isocyanates can cause irritation of the respiratory organs and hypersensitive reactions. Asthma sufferers, those with allergies and anyone with a history of respiratory complaints must not be asked to work with products containing isocyanates.

Do not sand, flame cut, braze or weld dry coating without a NIOSH approved air purifying respirator with particulate filters or appropriate ventilation, and gloves.

Revised: December 2021

In the United States and Canada:
1.855.6.AXALTA
metalux.us

